#### MOLECULAR SEROLOGY PROCEDURES MANUAL

Body Fluid Identification by Proteomic Mass Spectrometry - Digestion		
Status: Published  DATE EFFECTIVE	APPROVED BY	Document ID: 77457 PAGE
07/10/2023	Molecular Serology Technical Leader	1 OF 3

# **Body Fluid Identification by Proteomic Mass Spectrometry - Digestion**

## 1 Purpose

1.1 Overnight digestion of samples for Body Fluid Proteomics Assay to identify specific body fluids on evidence samples using liquid chromatography and mass spectrometry.

## **2 Protein Digestion Day 1 Procedure**

- 2.1 Input Concentration Avg values from Quant Batch into Digestion Batch in LIMS.
- 2.2 Ensure copy and paste from Quant batch into Digestion Batch was done correctly.
- 2.3 Retrieve sample Extraction tubes and positive control extracts from -20°C.
- 2.4 **Label WITNESS**: Have a witness verify that correct tubes are present in the set and the labels on input tubes match labels on output tubes.
- 2.5 Pipette volumes calculated (10 µg protein for non-LOW QUANT samples) by the LIMS into new 1.5 microcentrifuge Digestion tube.
  - Note: Always transfer 50 μl of Eneg extract.
- 2.6 Place Extraction tube in -20°C freezer.
- 2.7 Turn on both Mini-Shakers and set to 37°C and 55°C respectively.
- 2.8 Retrieve the 250 mM TCEP solution from freezer (-20°C) and record the identification number in LIMS. Add a tick mark to microcentrifuge tube; do not allow more than 5 freeze-thaw cycles. Place on ice or in a -20°C cold tube rack.
- 2.9 Add 1 µl of 250 mM TCEP into all tubes. Vortex and short spin on benchtop centrifuge.
- 2.10 Incubate for 30 minutes on the Mini-Shaker at 55°C at 200 RPM. Record instrument and temperature in LIMS.
- 2.11 Retrieve the 500 mM IAA from freezer (-20°C) and record the identification number in LIMS. Add a tick mark to microcentrifuge tube; do not allow more than 5 freeze-thaw cycles. Place on ice or in a -20°C cold tube rack.
- 2.12 Remove sample tube from heating Mini-Shaker incubator and let cool to room temperature for five minutes.

#### MOLECULAR SEROLOGY PROCEDURES MANUAL

Body Fluid Identification by Proteomic Mass Spectrometry -Digestion			
Status: Published DATE EFFECTIVE	APPROVED BY	Document ID: 77457 PAGE	
07/10/2023	Molecular Serology Technical Leader	2 OF 3	

- 2.13 Add 1.5 µl of 500 mM IAA into all tubes. Vortex and short spin on benchtop centrifuge.
- 2.14 Incubate in the dark (in drawer) at room temperature for 20 minutes.
- 2.15 Retrieve 500 mM DTT from freezer (-20°C) and record the identification number in LIMS. Add a tick mark to microcentrifuge tube; do not allow more than 5 freeze-thaw cycles. Place on ice or in a -20°C cold tube rack.
- 2.16 Add 1.5µl of 500 mM DTT into all tubes. Vortex and short spin on benchtop centrifuge.
- 2.17 Incubate at room temperature for 20 minutes (on the bench, darkness not required).
  - Note: Sample may or may not turn opaque, continue regardless.
- 2.18 Retrieve 0.5 μg/μl trypsin from freezer (-80°C) and record the identification number in LIMS. Add a tick mark to microcentrifuge tube; do not allow more than 5 freeze-thaw cycles. Place on ice or in a -20°C cold tube rack.
- 2.19 Add  $1\mu l$  of 0.5  $\mu g/\mu l$  trypsin into all tubes. Vortex and short spin on benchtop centrifuge.
- 2.20 Incubate at 37°C in Mini-Shaker overnight (17±1 hours) at 200 RPM. Record instrument and temperature in LIMS.

## 3 Protein Digestion Day 2 Procedure

3.1 Retrieve the following reagents and consumables, record the lot and identification numbers into LIMS.

	*
Formic A	eid (FA) at 4°C
Breathe-ea	asy breathable tube membrane

- 3.2 Remove tube from incubator and quick spin on benchtop centrifuge for 5 seconds to pellet droplets on lid.
- 3.3 Add 2.8 µl of formic acid to all tubes and vortex.
- 3.4 Spin tube in benchtop centrifuge at 12,000 g for 15 minutes.
- 3.5 **Transfer Witness:** Witness tube top labels and LIMS labels match.
- 3.6 Transfer the following volumes into new 1.5ml microcentrifuge tubes:
  - 3.6.1 **REGULAR Samples**: Transfer 50 µl of the digested supernatant. Quick spin on benchtop centrifuge.

### MOLECULAR SEROLOGY PROCEDURES MANUAL

Body Fluid Identification by Proteomic Mass Spectrometry -Di				
Status: Published	Document ID: 77457			
DATE EFFECTIVE	APPROVED BY	PAGE		
07/10/2023	Molecular Serology Technical Leader	3 OF 3		

- 3.6.2 **LOW Concentration Samples** (i.e., those with < 0.2 μg/μl): Transfer total sample volume. Record sample volume in LIMS. Quick spin on benchtop centrifuge.
- 3.7 Place Breathe-Easier Breathable Tube Membrane on top of open tubes.
- 3.8 Dry sample in SpeedVac (no temperature setting required) until samples are dry. (Check if sample is dry in 1-hour increments, do not surpass 2 hours.)
- 3.9 Remove Breathe-Easier Breathable Tube Membranes and store dried digestion tubes at -20°C.

